


# FIRST IMPRESSIONS FOR KIDS


1.) Set the Main Frame upright (G) and attach the cross support trays



(H) Using the four one inch bolts, (D) rubber washers (E) and a screw driver, screw the bolts in to place. (see below)



2.) Attach the two paper supports (I) using the four 1 inch wood screws (F) to the sides of the Main Frame (G)




3.) Attach the four Legs (K) using the 2" bolts (A), brass washers (B) and the wingnuts (C).







4.) Attach the two bottom cross supports (j) to the legs (K) on each side of the easel using the 2" bolts (A), brass washers (B), and the wingnuts (C).



5.) Insert the wonder dowel (L) through the paper roll (M) and set between the two paper supports (I)



6.) Place the bottoms in to each bucket (P) and strap them in to the bottom cross supports (J).



Place the Lids (N) on to the cups (O) and insert the cups in to the holes on the cross support trays (H) (as seen below.)

